



JRM-2

Router Motor

JR027 ~230V 50Hz


PARTS LIST



Импортер в РФ: ООО «ИТА Технолоджи»
105320 Москва, Переведеновский пер., д. 17
www.jetools.ru

Made in PRC / Сделано в КНР
P-JR027 2025-10

Parts Breakdown for JRM-2 Router Motor



Parts List for JRM-2 Router Motor

Index No.	Part No.	Description	Size	Qty
1	<u>JRM2-001</u>	<u>Main PCB</u>	-	1
2	<u>GB/T845</u>	<u>Self-taping Screw</u>	<u>ST2.9x20</u>	4
3	<u>GB/T6560</u>	<u>HS Self-taping Screw</u>	<u>ST4.2x15</u>	4
4	<u>JRM2-004</u>	<u>Bearing Seat</u>	-	1
5	<u>GB/T6560</u>	<u>Self-taping Screw</u>	<u>ST4.2x12</u>	4
6	<u>JRM2-006</u>	<u>Brush Holder ASSY</u>	-	2
7	<u>GB818</u>	<u>Pan Head Cap Machine Screw</u>	<u>M3x6</u>	4
8	<u>JRM2-008</u>	<u>Teeth Washer</u>	-	4
9	<u>JRM2-009</u>	<u>Carbon Brush</u>	-	2
10	<u>JRM2-010</u>	<u>Inner Housing</u>	-	1
11	<u>GB/T6560</u>	<u>Sel-taping Screw</u>	<u>ST5x70</u>	2
12	<u>JRM2-012</u>	<u>Motor Stator</u>	-	1
13	<u>JRM2-013</u>	<u>Motor End Cover</u>	-	1
14	<u>GB/T6560</u>	<u>Self-taping Screw</u>	<u>ST4.2x14</u>	6
15	<u>JRM2-015</u>	<u>Press Plate</u>	-	1
16	<u>JRM2-016</u>	<u>Magnetic ASSY</u>	-	1
17	<u>GB276</u>	<u>Bearing</u>	<u>6200-2RZ</u>	1
18	<u>JRM2-018</u>	<u>Armature ASSY</u>	-	1
19	<u>JRM2-019</u>	<u>Inner Sleeve</u>	-	1
20	<u>JRM2-020</u>	<u>Motor AL Housing</u>	-	1
21	<u>GB/T6560</u>	<u>Self-taping Screw</u>	<u>ST5x25</u>	4
22	<u>GB276</u>	<u>Bearing</u>	<u>6004-2RS</u>	1
23	<u>JRM2-023</u>	<u>Block Dust Plate</u>	-	1
24	<u>JRM2-024</u>	<u>Bearing Press Plate</u>	-	1
25	<u>GB819.1</u>	<u>Countersink Screw</u>	<u>M5x15</u>	3
26	<u>JRM2-026</u>	<u>MainCable -5 core</u>	-	1
27	<u>GB6171</u>	<u>Hex Nut</u>	<u>M3</u>	4
28	<u>JRM2-028</u>	<u>Fibre Washer</u>	-	4
29	<u>JRM2-029</u>	<u>Spacer Screw</u>	-	4
30	<u>GB819.1</u>	<u>Countersink Screw</u>	<u>M3x16</u>	4
31	<u>GB70.2</u>	<u>Socket Head Cap Screw</u>	<u>M4x12</u>	4
32	<u>JRM2-032</u>	<u>Control Box-Cover (Include #50)</u>	-	1
33	<u>GB70.2</u>	<u>Socket Head Cap Screw</u>	<u>M6x12</u>	4
34	<u>JRM2-034</u>	<u>Mounting Bracket</u>	-	1
35	<u>JRM2-035</u>	<u>Control Speed PCB</u>	-	1
36	<u>JRM2-036</u>	<u>Control Box-Bottom</u>	-	1
37	<u>JRM2-037</u>	<u>Control Knob</u>	-	1
38	<u>GB818</u>	<u>HSC Pan Head Cap Screw</u>	<u>M5x14</u>	1
39	<u>JRM2-039</u>	<u>Teeth Washer</u>	-	2
40	<u>GB41</u>	<u>Hex Nut</u>	<u>M5</u>	1
41	<u>JRM2-041</u>	<u>Socket Wire ASSY</u>	-	1
42	<u>JRM2-042</u>	<u>Power Switch</u>	-	1
43	<u>JRM2-043</u>	<u>Wire Mount Fitting</u>	<u>M18x1.5</u>	1

Parts List for JRM-2 Router Motor

Index No.	Part No.	Description	Size	Q'ty
44	JRM2-044	Power Cord		1
45	JRM2-045	Collet Seats		1
46	JRM2-046	ER20-Collet Nut		1
47	JRM2-047	1/4" ER20-Collet		1
48	JRM2-048	1/2" ER20-Collet		1
49	JRM2-049	Wrench	30.5mm	2
50	JRM2-050	<u>Control Label</u>	-	1

Wiring Diagram for JRM-2 Router Motor

	meaning of symbol	Bedeutung der Zeichen	Interprétation
M	motor	Motor	mot
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschuttschalter	déclencheur surcharge
L	machine lamp	Maschinenleuchte	lampe
LS	limit switch	Positionsendschalter	micro

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

Wiring Diagram for JRM-2 Router Motor

JR027..... ~ 230V, 50Hz

