



MBS-1013CSD Miter Bandsaw

MBS-1013CSD... 50000432T 3~400V, 50Hz

PARTS LIST



JPW Tool Group Hong Kong Limited
98 Granville Road, Tsimshatsui East, Kowloon, Hong Kong, PRC
www.jettools.com


Импортер в РФ: ООО «ИТА Технолоджи»
105082, Москва, Переведеновский пер., д. 17
www.jettools.ru

Made in Taiwan / Сделано на Тайване

P-50000432T

2023-07

MBS-1013CSD Stand Assembly




MBS-1013CSD Stand Assembly

Index No.	Part No.	Description	Size	Q'ty
1	MBS-1013CSD-01N	Base (Bottom Plate)		1
2	MBS-1013CSD-02N	Base (Left Part)		1
3	MBS-1013CSD-03N	Base (Right Part)		1
3-1	MBS-1013CSD-03-1N	Washer	M10x25x2	4
3-2	TS-1491021E	Hex. Cap Bolt	M10x20	4
4	MBS-1013CSD-04N	Base (Front Part)		1
4-1	TS-1490021E	Hex. Cap Bolt	M8x16	4
4-2	MBS-1013CSD-04-2N	Washer	M8x18x2	4
5	TS-1492041E	Hex. Cap Bolt	M12x40	2
6	MBS-1013CSD-06N	Nut	M12	2
8	TS-1490021E	Hex. Cap Bolt	M8x16	4
8-1	MBS-1013CSD-08-1N	Washer	M8x18x2	4
9	MBS-1013CSD-09N	Plate		1
10	TS-1502011E	Hex. Socket Cap Screw	M5x8	4
11	MBS-1013CSD-11	Coolant Tank		1
12	TS-2228161E	Hex. Cap Bolt	M8x16	2
13	MBS-1013CSD-13	Coolant Gauge		1
13-1	MBS-1013CSD-13-1	Nut	M10	2
13-2	MBS-1013CSD-13-2	Washer	M10x10x3	2
14	TS-2210161E	Hex. Cap Bolt	M10x16	2
15	MBS-1013CSD-15	Tank Cover		1
16	MBS-1013CSD-16	Filter		1
17	MBS-1013CSD-17	Pump		1
18	TS-1503061E	Hex. Socket Cap Screw	M6x25	2
18-1	MBS-1013CSD-18-1	Washer	M6x13x1	2
19	MBS-1013CSD-19N	Base (Rear Part)		1
19-1	TS-1503011E	Hex. Socket Cap Screw	M6x8	4
20	MBS-1013CSD-20N	Plate		1
21	TS-1502011E	Hex. Socket Cap Screw	M5x8	4
22	MBS-1013CSD-22	Hose Clamp	13mm	1
23	MBS-1013CSD-23	Hose	5/16"x254cm	1
23-1	MBS-1013CSD-23-1	Hose	1"x43cm	1
24B	MBS-1013CSD-24B	Coolant and Chip Tray		1
24-1	MBS-1013CSD-24-1	Plate		4
24-2	TS-1491021E	Hex. Cap Bolt	M10x20	4
24-3	MBS-1013CSD-24-3	Nut	M10	4
24-4A	MBS-1013CSD-24-4A	Coolant Plate		1
25	MBS-1013CSD-25	Mounting Bracket		2
25-1	TS-1504031E	Hex. Socket Cap Screw	M8x16	2
26	MBS-1013CSD-26	Spring Washer	M10	4
27	TS-1505021E	Hex. Socket Cap Screw	M10x20	4
28	MBS-1013CSD-28	Washer	M10x25x2	4
29	TS-1491021E	Hex. Cap Bolt	M10x20	4
29-1	MBS-1013CSD-29-1	Washer	M10	4
30	TS-1492041E	Hex. Cap Bolt	M12x40	2
31	MBS-1013CSD-31	Nut	M12	2
37-1	MBS-1013CSD-37-1	Hole Cover	HP-25	3
37-2	MBS-1013CSD-37-2	Hole Cover	HP-19	1
38-1	MBS-1013CSD-38-1	Hole Cover	HP-22	1
39	MBS-1013CSD-39N	Shaft Seat		2
40	TS-1504051E	Hex. Socket Cap Screw	M8x25	4
41	MBS-1013CSD-40-2	Spring Washer	M8	4
42	TS-1523041E	Set Screw	M6x12	10
43	MBS-1013CSD-43N	Shaft	SCF16x460	1
44	MBS-1013CSD-44	Roller Stand		1
45	TS-1492011E	Hex. Cap Bolt	M12x25	2
46	MBS-1013CSD-46	Spring Washer	M12	2

MBS-1013CSD Stand Assembly

Index No.	Part No.	Description	Size	Q'ty
46-1	MBS-1013CSD-46-1	Washer	M12x28x3	2
47	MBS-1013CSD-47	Roller		1
48	BB-6004ZZE	Ball Bearing	6004ZZ	2
48-1	MBS-1013CSD-48-1	C-Ring	S-20	2
49	MBS-1013CSD-49	Roller Shaft		1
50	TS-1504041E	Hex. Socket Cap Screw	M8x20	2
50-1	MBS-1013CSD-50-1	Spring Washer	M8	2

MBS-1013CSD Swivel & Base Assembly



MBS-1013CSD Swivel & Base Assembly

Index No.	Part No.	Description	Size	Q'ty
61	MBS-1013CSD-61	Handle	M12x25	1
62	MBS-1013CSD-62	Nut	M12	1
63	MBS-1013CSD-63	Locking Lever		1
63-1	TS-1525031E	Set Screw	M10x16	1
64	TS-1505051E	Hex. Socket Cap Screw	M10x35	1
64-1	MBS-1013CSD-64-1	Spring Washer	M10	1
65	MBS-1013CSD-65	Shaft Nut		1
65-1	MBS-1013CSD-65-1	Oil Seal		1
65-3A	MBS-1013CSD-65-3A	Disk		1
65-4	MBS-1013CSD-65-4	Spring Washer	M8	4
65-5	TS-1504071E	Hex. Socket Cap Screw	M8x35	4
65-6	MBS-1013CSD-65-6	DU Plate		6
65-7	MBS-1013CSD-65-7	Flat Head Hex Socket Screw	M4x8	6
66A	MBS-1013CSD-66A	Shaft		1
68A	MBS-1013CSD-68A	Swivel Arm		1
68-1	TS-1491051E	Hex. Cap Bolt	M10x35	1
68-2	MBS-1013CSD-68-2	Oil Inlet	1/16"	2
69	MBS-1013CSD-69	Scale	0-60°	1
69-1	MBS-1013CSD-69-1	Scale	0-45°	1
70	MBS-1013CSD-70	Rivet	2.3x4	4
71	MBS-1013CSD-71	Pin		1
72	MBS-1013CSD-72	Hollow Pin	ø 2.5x16	1
73	MBS-1013CSD-73	Spring		1
74	MBS-1013CSD-74	Bushing		1
75	MBS-1013CSD-75	Bracket		1
76	MBS-1013CSD-76	Spring Washer	M8	2
77	TS-1504051E	Hex. Socket Cap Screw	M8x25	2
78	MBS-1013CSD-78	Knob		1
79	MBS-1013CSD-79	Jam Nut	M40	1
80	MBS-1013CSD-80	Star Washer	M40	1
81	MBS-1013CSD-81	Anti-Dust Cover	M40	2
82	BB-32008E	Ball Bearing	32008	2
83A	MBS-1013CSD-83A	Shaft		1
84	TS-2210451E	Hex. Cap Bolt	M10x45	1
85	MBS-1013CSD-85	Nut	M10	2
86A	MBS-1013CSD-86A	Pointer		2
87	TS-1502011E	Hex. Socket Cap Screw	M5x8	2
88A	MBS-1013CSD-88A	Cover		1
88-1	MBS-1013CSD-88-1	Hollow Pin	ø 6x20	2
88-2	TS-1524021E	Set Screw	M8x10	1
89	MBS-1013CSD-89	Hex. Socket Cap Screw	M8x35	5
89-1	MBS-1013CSD-89-1	Spring Washer	M8	5
92B	MBS-1013CSD-92B	Table		1
92-1	TS-1523041E	Set Screw	M6x12	1
92-2	MBS-1013CSD-92-2	Changeable Plate		1
92-3	TS-1504031E	Hex. Socket Cap Screw	M8x16	4
93	TS-1505021E	Hex. Socket Cap Screw	M10x20	2
93-1	MBS-1013CSD-93-1	Washer	M10x25x2	4
94	MBS-1013CSD-94	Bar-Stop-Rod		1
95A	MBS-1013CSD-95A	Bar Bracket		1
95-1	MBS-1013CSD-95-1	Nut	M8	2
95-2	TS-1504051E	Hex. Socket Cap Screw	M8x25	1
95-4	MBS-1013CSD-95-4	Stop Bar		1
96	MBS-1013CSD-96	Handle	M8x25	1
97	MBS-1013CSD-97	Scale		1
98	MBS-1013CSD-98	Rivet	2x5	3
99	MBS-1013CSD-99	Chip Gutter		1
100	TS-1503011E	Hex. Socket Cap Screw	M6x8	2
102	MBS-1013CSD-102	Vise Jaw – Right (2303V00867 and lower)		1

MBS-1013CSD Swivel & Base Assembly

Index No.	Part No.	Description	Size	Q'ty
.....	1013CSD-102N.....	Vise Jaw – Right (23xxV00868 and higher).....		1
103.....	TS-1503041E.....	Hex. Socket Cap Screw.....	M6x16.....	2
104.....	MBS-1013CSD-104....	Vise Jaw – Left (2303V00867 and lower).....		1
.....	1013CSD-104N.....	Vise Jaw – Left (23xxV00868 and higher).....		1
.....	1013CSD-VJA.....	Vise Jaw Assembly (including 102,104) (23xxV00868 and higher).....		1
105.....	TS-1503041E.....	Hex. Socket Cap Screw.....	M6x16.....	2
106.....	MBS-1013CSD-106....	Vise Jaw - Front.....		1
107.....	TS-1534051E.....	Flat Head Machine Screw.....	M6x16.....	2
108A.....	MBS-1013CSD-108A..	Movable Vise.....		1
109.....	MBS-1013CSD-109....	Dovetail Plate.....		1
110.....	MBS-1013CSD-110....	Nut.....	M5.....	3
111.....	MBS-1013CSD-111....	Set Screw.....	M5x25.....	3
113.....	MBS-1013CSD-113....	Key.....	5x5x15.....	1
115.....	MBS-1013CSD-115....	Spring Washer.....	M8.....	4
116.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20.....	4
117.....	MBS-1013CSD-117....	Hand Wheel.....	6-1/2".....	1
117-1.....	MBS-1013CSD-117-1.	Spring Washer.....	M6.....	1
117-2.....	TS-1503061E.....	Hex. Socket Cap Screw.....	M6x25.....	1
117-3.....	MBS-1013CSD-117-3.	Bushing.....		1
118.....	TS-1524021E.....	Set Screw.....	M8x10.....	1
.....	MBS-1013-TVSA.....	Table and Vise Seat Assembly.....		
.....	(including 92B~93-1,109,120B~126) (serial no. 2011V02035 and higher)			
120B.....	MBS-1013CSD-120B..	Vise Seat (Wedge type).....		1
121.....	MBS-1013CSD-121....	Position Seat.....		1
121-1.....	TS-1505021E.....	Hex. Socket Cap Screw.....	M10x20.....	2
122.....	MBS-1013CSD-122N..	Block.....		1
123.....	MBS-1013CSD-123N..	Eccentric Shaft.....		1
123-1.....	MBS-1013CSD-123N-1	Ring.....	S-18.....	2
124.....	MBS-1013CSD-124N..	Handle.....	TRT80 M10x25.....	1
125.....	MBS-1013CSD-125N..	Nut.....	M10.....	1
126.....	MBS-1013CSD-126....	Spring Washer.....	M10.....	1
127.....	MBS-1013CSD-127N..	Linear Bearing Bracket.....		1
128.....	TS-1504051E.....	Hex. Socket Cap Screw.....	M8x25.....	2
128-1.....	MBS-1013CSD-128-1.	Spring Washer.....	M8.....	2
129.....	MBS-1013CSD-129N..	Bearing.....		1
130.....	MBS-1013CSD-130N..	Ring.....	S-28.....	2
131.....	MBS-1013CSD-131....	Electric Box Holder.....		1
132.....	MBS-1013CSD-132....	Spring Washer.....	M8.....	4
133.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20.....	4
135.....	TS-1505031E.....	Hex. Socket Cap Screw.....	M10x25.....	2
136.....	MBS-1013CSD-136....	Spring Washer.....	M10.....	2
137.....	MBS-1013CSD-137....	Support.....		1
137-1.....	TS-1502011E.....	Hex. Socket Cap Screw.....	M5X8.....	4
138.....	MBS-1013CSD-138....	Control Box Bottom Part.....		1
139.....	MBS-1013CSD-139....	Control Box Panel.....		1
139-1.....	MBS-1013CSD-139-1.	Blade Speed Indicator.....		1
139-2.....	MBS-1013CSD-139-2.	Hex. Socket Cap Screw.....	M3X20.....	2
139-3.....	MBS-1013CSD-139-3.	Round Head Screw.....	M5X8.....	6
139-4.....	MBS-1013CSD-139-4.	Nut.....	M3.....	2
140.....	MBS-1013CSD-140....	Manual / Auto Selector.....		1
141.....	MBS-1013CSD-141....	Blade Speed Knob.....		1
142.....	MBS-1013CSD-142....	Emergency Switch.....		1
143.....	MBS-1013CSD-143....	Main Connect Switch.....		1
144.....	MBS-1013CSD-144....	Blade Start / Stop Button.....		1
145.....	MBS-1013CSD-145....	Indicator Light.....		1
146.....	MBS-1013CSD-146....	Control Box Bottom Plate.....		1
146-1.....	MBS-1013CSD-146-1N	Inverter.....		1
146-2.....	MBS-1013CSD-146-2.	Transformer.....		1
146-3.....	MBS-1013CSD-146-3.	Fuse.....	0.5A.....	1
146-4.....	MBS-1013CSD-146-4.	Relay.....		1

MBS-1013CSD Swivel & Base Assembly

Index No.	Part No.	Description	Size	Q'ty
146-5	MBS-1013CSD-146-5	Terminal Connector		1
146-6	TS-1501021E	Hex. Socket Cap Screw	M4x8	4
146-7	MBS-1013CSD-146-7	Grounding Plate		1
146-8	MBS-1013CSD-146-8	Wire Channel		1
147	TS-1502011E	Hex. Socket Cap Screw	M5X8	4
148	MBS-1013CSD-148	Control Box Cover		1
149	MBS-1013CSD-149	Supporting Bracket		1
149-1	MBS-1013CSD-149-1	Shaft		1
150	TS-1524021E	Set Screw	M8x10	1
150-1	TS-1504041E	Hex. Socket Cap Screw	M8x20	4
150-2	MBS-1013CSD-150-2	Spring Washer	M8	4
286A	MBS-1013CSD-286A	Lead Screw		1
286-1	MBS-1013CSD-286-1	Spring		1
286-2	TS-1504031E	Hex. Socket Cap Screw	M8x16	1
286-3	MBS-1013CSD-286-3	Washer	M8	1
287	MBS-1013CSD-287	Setting Seat		1
288	MBS-1013CSD-288	Lock Handle		1
289	MBS-1013CSD-289	Bearing Bushing		1
289-1	BB-51104E	Ball Bearing	51104	1
289-2	MBS-1013CSD-289-2	Nut	M20	1
289-3	TS-1522011E	Set Screw	M5x6	1


MBS-1013CSD Bow Assembly

Index No.	Part No.	Description	Size	Q'ty
151	MBS-1013CSD-151	Reduction Unit		1
151-1	MBS-1013CSD-151-1	Vent Screw	1/4"	1
152	MBS-1013CSD-152	Key	8x7x30	1
153	TS-1490041E	Hex. Cap Bolt	M8x25	4
153-1	MBS-1013CSD-153-1	Spring Washer	M8	4
154	MBS-1013CSD-154	Motor	1.5kW 400V 3 Ph	1
154-1	MBS-1013CSD-154-1	Junction Box		1
155	MBS-1013CSD-155	Key	8x7x40	1
186	TS-1505051E	Hex. Socket Cap Screw	M10x35	4
186-1	MBS-1013CSD-186-1	Spring Washer	M10	4
193B	MBS-1013CSD-193B	Saw Arm		1
193-1	TS-1524021E	Set Screw	M8x10	2
194	TS-1505051E	Hex. Socket Cap Screw	M10x35	4
194-1	MBS-1013CSD-194-1	Spring Washer	M10	4
195	MBS-1013CSD-195	Limit Switch		1
195-1	MBS-1013CSD-195-1	Switch Pin		1
196	MBS-1013CSD-196	Hex. Socket Cap Screw	M4x30	2
197	TS-1505051E	Hex. Socket Cap Screw	M10x35	4
197-1	MBS-1013CSD-197-1	Spring Washer	M10	4
198A	MBS-1013CSD-198A	T Connector		1
199	TS-1502041E	Hex. Socket Cap Screw	M5x16	2
200	MBS-1013CSD-200	Coolant Switch		2
201	MBS-1013CSD-201	Hose Clamp	13mm	1
203	MBS-1013CSD-203	Pipe Fitting	1/4Px5/16	1
204	MBS-1013CSD-204	Hose	5/16"x120cm	1
205	MBS-1013CSD-205	Hose	5/16"x50cm	1
206	MBS-1013CSD-206	Drive Flywheel		1
207	MBS-1013CSD-207	Washer		1
207-1	MBS-1013CSD-207-1	Spring Washer	M10	1
208	TS-1491031E	Hex. Cap Bolt	M10x25	1
209A	MBS-1013CSD-209A	Idle Flywheel Shaft		1
210	BB-32007E	Roller Bearing	32007	2
211	MBS-1013CSD-211	Idle Flywheel		1
212	MBS-1013CSD-212	Star Washer	M35	1
212-1	MBS-1013CSD-212-1	Anti-dust Cover	M35	2
213	MBS-1013CSD-213	Jam Nut	M35	1
214	MBS-1013CSD-214	Oil Inlet	1/16"	1
215A	MBS-1013CSD-215A	Saw Blade		1
216B	MBS-1013CSD-216B	Blade Cover		1
216A-1	MBS-1013CSD-216A-1	Coolant Tray		1
216A-2	MBS-1013CSD-216A-2	Round Head Screw	M6x8	2
217	MBS-1013CSD-217	Plum Screw	M6x12	4
219	MBS-1013CSD-219	Round Head Screw	M4x8	2
220	MBS-1013CSD-220	Nut	M4	2
222	MBS-1013CSD-222	Handle		2
223	MBS-1013CSD-223	Handle Wheel		1
223-1	BB-51103E	Thrust Bearing	51103	1
223-2	MBS-1013CSD-223-2	Blade Tension Gauge		1
223-3	MBS-1013CSD-223-3	Plate		1
224	MBS-1013CSD-224	Special Spring Washer		10
225	MBS-1013CSD-225	Tension Shaft		1
229	MBS-1013CSD-229	Plate		1
230	TS-1503031E	Hex. Socket Cap Screw	M6x12	2
230-1	MBS-1013CSD-230-1	Washer	M6x13x1	2
231	MBS-1013CSD-231	Limit Switch		1
232	TS-1501071E	Hex. Socket Cap Bolt	M4x25	2
239	MBS-1013CSD-239	Nut	M16	1

MBS-1013CSD Bow Assembly

Index No.	Part No.	Description	Size	Q'ty
240A	MBS-1013CSD-240A	Slide Bracket		1
240A-1	MBS-1013CSD-240A-1	Spring Washer	M10	3
240A-2	TS-1505071E	Hex. Socket Cap Screw	M10x45	3
240A-3	TS-1525051E	Set Screw	M10x25	1
244	MBS-1013CSD-244	Cover Plate		1
245	TS-1503011E	Hex. Socket Cap Screw	M6x8	2
246	MBS-1013CSD-246	Gib		2
247	MBS-1013CSD-247	Spring Washer	M8	6
248	TS-1504041E	Hex. Socket Cap Screw	M8x20	6
252	MBS-1013CSD-252	Setting Bracket		1
253	MBS-1013CSD-253	Knob	Ø70	1
254	MBS-1013CSD-254	Handle	M6x60	1
277	TS-1505021E	Hex. Socket Cap Screw	M10x20	2
291	HS-201402	Head Lever Handgrip		1
292	MBS-1013CSD-292	Pipe		1
292-1	MBS-1013CSD-292-1	Nut	M16	1
293	MBS-1013CSD-293	Nut	M12	1
294	MBS-1013CSD-294	Spring Hook		1
295	MBS-1013CSD-295	Spring		1
296	MBS-1013CSD-296	Spring Seat		1
297	MBS-1013CSD-297	Spring Bushing		1
298	MBS-1013CSD-298	C-Ring	S-12	4
298-1	MBS-1013CSD-298-1	Washer	M10	2
299	MBS-1013CSD-299	Shaft		1
300	MBS-1013CSD-300	Pin		1
301	MBS-1013CSD-301	Hollow Pin	2.5x16	1
302	MBS-1013CSD-302	Spring		1
303	MBS-1013CSD-303	Handle	M10x70	1
304	MBS-1013CSD-304	Nut	M10	1
305	MBS-1013CSD-305	Adjusting Bracket		1
306	MBS-1013CSD-306	Shaft		1
307	MBS-1013CSD-307	Knob		1
307-1	MBS-1013CSD-307-1	Bushing		1
308	MBS-1013CSD-308	Shaft		1
309	MBS-1013CSD-309	Arm		1
310	MBS-1013CSD-310	C-Ring	S-12	2
311	TS-1505031E	Hex. Socket Cap Screw	M10x25	1
312	MBS-1013CSD-312	Spring Washer	M10	1
313	MBS-1013CSD-313	Post		1
314	TS-1525031E	Set Screw	M10x16	3
315	MBS-1013CSD-315	Hydraulic Cylinder Post		1
316	MBS-1013CSD-316	Spring Washer	M8	4
317	TS-1504051E	Hex. Socket Cap Screw	M8x25	4
318	MBS-1013CSD-318	Round Head Screw	M5X10	2
319	MBS-1013CSD-319	Limit Switch		1
320	TS-1503011E	Hex. Socket Cap Screw	M6X8	2
320-1	MBS-1013CSD-320-1	Washer	M6x13x1	2
321A	MBS-1013CSD-321A	Adjusting Bracket		1
322A	MBS-1013CSD-322A	Hydraulic Cylinder		1
323	TS-1505061E	Hex. Socket Cap Screw	M10x40	1
324	MBS-1013CSD-324	Nut	M10	1

MBS-1013CSD Bearing Guide Assembly



MBS-1013CSD Bearing Guide Assembly

Index No.	Part No.	Description	Size	Q'ty
249	MBS-1013CSD-249	Blade Guide Movable Rod	SS41 19x38x400	1
249-1	TS-1503011E	Hex. Socket Cap Screw	M6x8	1
250	TS-1523041E	Set Screw	M6x12	4
251	TS-1504041E	Hex. Socket Cap Screw	M8x20	2
254	MBS-1013CSD-254	Handle		1
256	MBS-1013CSD-256	Guide Bracket		1
259	MBS-1013CSD-259	Bolt		2
260	TS-1503011E	Hex. Socket Cap Screw	M6x8	1
261	MBS-1013CSD-261	Blade Guard		1
262	TS-1523041E	Set Screw	M6x12	2
263	MBS-1013CSD-263	Nut	M6	2
264	MBS-1013CSD-264	Centric Shaft		2
265	BB-608ZZE	Ball Bearing	608ZZ	8
265-1	BB-608ZZE	Ball Bearing	608ZZ	2
266	MBS-1013CSD-266	E-Ring	E-7	4
267	MBS-1013CSD-267	Blade Guide		2
268	TS-1503061E	Hex. Socket Cap Screw	M6x25	2
269	MBS-1013CSD-269	Eccentric Shaft		2
270	TS-1503011E	Hex. Socket Cap Screw	M6x8	2
271	MBS-1013CSD-271	Blade Guard		1
272	MBS-1013CSD-272	Guide Bracket		1
272-1	TS-1503011E	Hex. Socket Cap Screw	M6x8	2
273	MBS-1013CSD-273	Pipe Fitting	1/4Px5/16	2
274	MBS-1013CSD-274	Blade Guide		2
275	MBS-1013CSD-275	Ball Bearing Bracket		1
276	TS-1523041E	Set Screw	M6x12	4
279	TS-1504041E	Hex. Socket Cap Screw	M8x20	2
280	MBS-1013CSD-280	Brush	Ø50	1
281	MBS-1013CSD-281	Brush Clamp		1
282	TS-1522011E	Set Screw	M5x6	1
283	MBS-1013CSD-283	Set Bushing		1
284	TS-1482021E	Hex. Cap Screw	M6x12	2
285	MBS-1013CSD-285	Washer	M6x13x1	2

