



JWBS-14SFX

Band Saw

JT1-394.....230V 50Hz

PARTS LIST



JPW Tool Group Hong Kong Limited

98 Granville Road, Tsimshatsui East, Kowloon, Hong Kong, PRC
www.jettools.com

Импортёр в РФ: ООО «ИТА Технологии»


105082, Москва, Переведеновский пер., д. 17
www.jettools.ru

Made in PRC / Сделано в КНР


P-JT1-394

2023-08


Exploded View for JWBS-14SFX Band Saw




Exploded View for JWBS-14SFX Band Saw



Exploded View for JWBS-14SFX Band Saw



Optional Accessory



JWBS-14SFX Band Saw (#714400M) – Parts List

Index No	Part No	Description	Size	Qty
002	JWBS14SFX-002	Upper Wheel Shaft		1
003	JWBS14SFX-003	Upper Wheel Axis Seat		1
004	JWBS14SFX-004	U-Bracket		1
005	JWBS14SFX-005	Guide Plate		1
006	JWBS14SFX-006	Tension Pointer		1
007	JWBS14SFX-007	Shaft		1
009	JWBS14SFX-009	Lower Wheel Shaft		1
012	JWBS14SFX-012	Lower Wheel Bracket		1
013	JWBS14SFX-013	Upper Guide Mount		1
014	JWBS14SFX-014	Eccentric Base		1
015	JWBS14SFX-015	Eccentric Shaft		1
016	JWBS14SFX-016	Worm		1
017	JWBS14SFX-017	Gear Shaft		1
018	JWBS14SFX-018	Gear		1
019	JWBS14SFX-019E	Motor Assembly	1.5kW, 230V	1
	JWBS14SFX-019EWD	Wiring Diagram (not shown)		1
	JWBS14SFX-019EML	Motor Label, JWBS-14SFX (not shown)	1.5kW, 230V	1
	JWBS14SFX-019MF	Motor Fan (not shown)		1
	JWBS14SFX-019MFC	Motor Fan Cover (not shown)		1
	JWBS14SFX-019ERC	Running Capacitor (not shown)	40µF, 450V AC	1
	JWBS14SFX-019ESC	Start Capacitor (not shown)	100µF, 275V AC	1
	JWBS14SFX-019JB	Junction Box (not shown)		1
	JWBS14SFX-019JBC	Junction Box Cover (not shown)		1
020	JWBS14SFX-020	Shaft		1
021	JWBS14SFX-021	Blade	116.25" x 5/8" x 0.025" x 4 TPI	1
022	JWBS14SFX-022	Door Lock Knob		2
023	JWBS14SFX-023	Knob		1
024	JWBS14SFX-024E	Power Cord		1
025	JWBS14SFX-025	Handwheel		1
027	JWBS14SFX-027	Wood Insert	70x113x7.5 mm	1
028	JWBS14SFX-028	Tension Handle and Grip		1
029	JWBS14SFX-029E	Switch Assembly	DZ-07B	1
030	JWBS14SFX-030	Shaft		1
032	JWBS14SFX-032	Upper Guide Square Tube		1
033	JWBS14SFX-033	Tension Indicator Plate		1
034	JWBS14SFX-034	Handle		1
036	JWBS14SFX-036	Upper Guide Rack		1
038	JWBS14SFX-038	Guide Pointer		1
039	JWBS14SFX-039	Plate		1
040	TS-1504031	Socket Head Cap Screw	M8x16	13
042	TS-1504061	Socket Head Cap Screw	M8x30	1
043	TS-1502051	Socket Head Cap Screw	M5x20	3
044	TS-1503031	Socket Head Cap Screw	M6x12	6
045	TS-1503071	Socket Head Cap Screw	M6x30	5
046	TS-1502021	Socket Head Cap Screw	M5x10	8
047	TS-1502071	Socket Head Cap Screw	M5x30	2
048	JWBS14SFX-048E	Socket Head Button Screw	M5x10	2
049	TS-2361081	Lock Washer	8mm	9
051	TS-2361101	Lock Washer	10mm	3
052	TS-1550061	Flat Washer	8mm	5
054	TS-1550071	Flat Washer	10mm	6
055	JWBS14SFX-051	Cutting Height Scale		1
057	TS-1550041	Flat Washer	6mm	5
058	TS-1550061	Flat Washer	8mm	5
059	F010422	Socket Set Screw, CPP	M10x50	1
060	TS-1523041	Socket Set Screw	M6x12	5
061	TS-1522011	Socket Set Screw	M5x6	3
063	JWBS14SFX-063	Lower Wheel Assembly (#63-1 thru 63-2)		1
063-1	JWBS14SFX-063-1	Lower Wheel		1
063-2	JWBS14SFX-063-2	Tire		1

Index No	Part No	Description	Size	Qty
064	JWBS14SFX-064	Upper Wheel Assembly (#64-1 thru 64-4)		1
064-1	JWBS14SFX-064-1 ...	Upper Wheel.....		1
064-2	JWBS14SFX-064-2 ...	Tire.....		1
064-3	BB-6203ZZ	Bearing	6203/2RZ	2
063-4	F006035	C-Retaining Ring, Internal	40mm	2
066	JWBS14SFX-066	Hinge Plate		1
067	JWBS14SFX-067	Dust Chute.....	100mm	2
068	JWBS14SFX-068	Protective Bending Plate		1
069	JWBS14SFX-069	Plate for Gear Box		1
070	JWBS14SFX-070	Gear Box Cover		1
071	JWBS14SFX-071A....	Blade Tension Shaft	200mm	1
072	JWBS14SFX-072	Connector Nut.....		1
	JWBS14SFX-072-1...	Cotter Pin (not shown)		1
074	JWBS14SFX-074	Knob		1
075	JWBS14SFX-075	Shaft		2
076	JWBS14SFX-076	Cord Clip		1
077	JWBS14SFX-077	Slotted Head Screw		1
078	JWBS14SFX-078	Sight Glass		1
079	JWBS14SFX-079	Spring		1
080	JWBS14SFX-080	Bolt.....		3
081	JWBS14SFX-081	Brush		1
082	JWBS14SFX-082	Spacer Bushing		1
083	JWBS14SFX-083	Lower Door		1
087	JWBS14SFX-087	Lock Handle.....		1
088	JWBS14SFX-088	Sleeve A		1
089	JWBS14SFX-089	Sleeve B		1
090	JWBS14SFX-090	Cover		1
091	JWBS14SFX-091	Thread Tube		1
092	JWBS14SFX-092	Collar		1
093	JWBS14SFX-093	Upper Guide Insert		1
094	JWBS14SFX-094	Washer A		2
095	JWBS14SFX-095	Washer B		2
096	JWBS14SFX-096	Plate.....		1
097	JWBS14SFX-097	Spring Plate		1
098	JWBS14SFX-098	Cover A.....		1
099	F009875	Socket Head Button Screw.....	M4x8	22
100	F009884	Socket Head Button Screw.....	M5x8	5
102	JWBS14SFX-102	Rivet.....	4x8mm	8
103	TS-2284082	Pan Head Machine Screw	M4x8	2
106	TS-154010	Hex Nut.....	M16	1
107	TS-1540081	Hex Nut.....	M12	3
109	TS-1540041	Hex Nut.....	M6	2
110	TS-1532052	Pan Head Machine Screw	M4x16	1
111	TS-2360121	Flat Washer	12mm	1
112	TS-1540021	Hex Nut.....	M4	1
114	BB-6205ZZ	Ball Bearing	6205/2RZ	2
116	TS-2276081	Socket Set Screw	M6x8	2
117	JWBS14SFX-117	Bearing Guide Rod		1
118	TS-1550021	Flat Washer	4mm	6
119	JWBS14SFX-119	Sleeve.....		2
120	TS-1541031	Nylon Lock Hex Nut	M8	1
122	JWBS14SFX-122	Carriage Bolt.....	M8x105	1
123	F014011	Key, Dbl Rd Hd	8x50mm	1
124	6294761	Key, Dbl Rd Hd	6x45mm	1
125	JWBS14SFX-125	Nylon Lock Hex Nut, LH thds	M18 Left	1
121	TS-1541011	Nylon Lock Hex Nut	M5	2
126	TS-2360181	Flat Washer	18mm	2
129	JWBS14SFX-129	Hex Nut	M18-1.5	1
130	JWBS14SFX-130	Strain Relief	M20-1.5	3
131	JWBS14SFX-131	Upper Door Assembly (#131-1 thru 131-3)		1
131-1	JWBS14SFX-131-1...	Upper Door		1

Index No	Part No	Description	Size	Qty
131-2	JWBS14SFX-131-2...	Rivet.....	4x8mm	4
131-3	JWBS14SFX-131-3...	Sight Glass	1
132	TS-1502021	Socket Head Cap Screw	M5x10	4
133	JWBS14SFX-133	Upper Guide Base	1
134	TS-1503051	Socket Head Cap Screw	M6x20	2
135	JWBS14SFX-135	Bearing Nut.....	2
136	BB-61900ZZ.....	Ball Bearing	61900/2RZ	10
137	TS-1550041	Flat Washer	6mm	4
138	JWBS14SFX-138	Lock Knob.....	3
139	JWBS14SFX-139	Eccentric Shaft.....	4
140	JWBS14SFX-140	Bearing Bushing	4
141	TS-1503031	Socket Head Cap Screw	M6x12	1
143	JWBS14SFX-143	Lower Table Trunnion.....	1
144	JWBS14SFX-144	Upper Table Trunnion.....	2
146	F009884	Socket Head Button Screw.....	M5x8	1
150	JWBS14SFX-150	Table Insert.....	1
151	JWBS14SFX-151	Table Pin.....	1
153	TS-1550031	Flat Washer	5mm	1
154	TS-1550061	Flat Washer	8mm	6
155	TS-1550071	Flat Washer	10mm	2
157	JWBS14SFX-157	Lock Handle.....	1
158	JWBS14SFX-158	Carriage Bolt.....	2
159	TS-1541031	Nylon Lock Hex Nut	M8	1
163	F009884	Socket Head Button Screw.....	M5x8	8
166	JWBS14SFX-166	Pointer	1
176	JWBS14SFX-176	Adjustable Handle	2
178	JWBS14SFX-178	Pin.....	1
179	F011652	Self-Tapping Screw	#8x3/8"	4
183	TS-2311081	Hex Nut.....	M8	3
184	TS-2311101	Hex Nut.....	M10	2
186	TS-1550031	Flat Washer	5mm	1
187	TS-1550071	Flat Washer	10mm	2
188	JWBS14SFX-188	Table.....	1
190	TS-1503051	Socket Head Cap Screw	M6x20	4
191	TS-1505061	Socket Head Cap Screw	M10x40	2
193	TS-2361101	Lock Washer.....	2
194	JWBS14SFX-194	Scale A	1
195	JWBS14SFX-195	Scale B	1
199	TS-1503041	Socket Head Cap Screw	M6x16	2
215	JWBS14SFX-215	Adjust Screw	1
221	JWBS14SFX-221	Motor Pulley	1
223	JWBS14SFX-223	Motor Plate	1
224	TS-1514011	Socket Head Flat Screw	M6x12	4
225	TS-1505041	Socket Head Cap Screw	M10x30	3
226	JWBS14SFX-226	Fence.....	1
227	JWBS14SFX-227	Carriage Bolt.....	2
228	JWBS14SFX-228	Lock Bar.....	1
229	JWBS14SFX-229	Cap for Fence Body	2
230	JWBS14SFX-230	Fence Body	1
231	JWBS14SFX-231	Guide Plate, Screw	1
232	TS-2246122	Socket Head Button Screw	M6x12	4
233	TS-1521011	Socket Set Screw	M4x4	4
234	JWBS14SFX-234	Connecting Plate	1
235	TS-1501041	Socket Head Cap Screw	M4x12	4
236	JWBS14SFX-236	Connecting Long Plate	2
237	JWBS14SFX-237	Left Cap for Fence Guide	1
238	JWBS14SFX-238	Lock Shaft	1
239	JWBS14SFX-239	Fence Guide	1
240	JWBS14SFX-240	Cursor Stop	1
241	JWBS14SFX-241	Cursor	1
242	JWBS14SFX-242	Right Cap for Fence Guide	1

Index No	Part No	Description	Size	Qty
243	TS-1533042	Pan Head Machine Screw	M5x12	2
244	JWBS14SFX-244	Low Stop Plate	2
245	JWBS14SFX-245	Insert Plate.....	M5.....	2
246	JWBS14SFX-246	Eccentric Locking Rod	1
247	JWBS14SFX-247	Lock Handle.....	1
248	JWBS14SFX-248	Eccentric Locking Spring	1
249	TS-2284082	Pan Head Machine Screw	M4x8	1
250	JWBS14SFX-250	Left Cap for Fence Rail.....	1
251	JWBS14SFX-251	Right Cap for Fence Rail	1
252	JWBS14SFX-252	Fence Rail Extrusion.....	1
253	TS-1490021	Hex Cap Screw.....	M8x16	4
254	JWBS14SFX-254	Plate.....	1
255	VB-A860	V-Belt	A-860La	1
256	JWBS14SFX-256	Fence Body Assembly (includes #176,179,227~249,254)	1
257	JWBS14SFX-257	Rail Assembly (includes #179,194,195,250~252)	1
261	TS-1503021	Socket Head Cap Screw	M6x10	2
262	JWBS14SFX-262	JET Logo with Adhesive	8.6"x8"	1
264	JWBS14SFX-264	Blade Guard	1
265	JWBS14SFX-265	Upper Guide Mount	1
266	JWBS14SFX-266	Wave Washer	6mm	2
267	JWBS14SFX-267	Knurled Lock Knob A	2
268	JWBS14SFX-268	Knurled Lock Knob B	2
269	JWBS14SFX-269	Knurled Lock Knob C	1
270	JWBS14SFX-270	Guide Base, Lower Guide	1
271	JWBS14SFX-271	Wedge Way Guide	1
272	JWBS14SFX-272	Lower Blade Guard	1
273	JWBS14SFX-273	Bearing Guide Rod	1
274	JWBS14SFX-274	Saw Body	1
281	JWBS14SFX-281	Upper Blade Guard & Guide Kit - for s/n2021083118 and Lower (#39, #55, #96, #97, #99, #103, #118, #264, #116, #119, #132, #133, #135 thru141; #265 thru 267; #273)	1
282	JWBS14SFX-282	Upper Blade Guard Kit - (#39, #55, #96, #97, #99, #103, #118, #264)	1	
283	JWBS14SFX-283	Upper Blade Guide Kit - (#116, #119, #132, #133, #135 thru141; #265 thru 267; #273)	1
288	JWBS14SFX-288	Light Kit (230V)	1
289	TS-1502041	Socket Head Cap Screw	M5x16	4
.....	LM000330E	ID Label, JWBS-14SFX (not shown)	1
.....	LM000331E	Warning Label, JWBS-14SFX (not shown)	1
.....	JET750-55	Hex wrench (not shown)	2.5mm	1
.....	TS-152704	Ball End Hex wrench (not shown)	3mm	1
.....	TS-152705	Hex Wrench wrench (not shown)	4mm	1
.....	TS-152706	Hex wrench (not shown)	5mm	1
.....	TS-152707	Hex wrench (not shown)	6mm	1
.....	TS-227D081	Hex Wrench (not shown)	8mm	1
.....	LM000332	Quick Release Label, JWBS-14SFX (not shown)	1
.....	JWBS14SFX-HPN	Hardware Package (see sect. 4.3 for contents; Fig.1)	
HP1	TS-1504101	Socket Head Cap Screw	M8x50	4
HP2	TS-2228161	Hex Cap Screw.....	M8x16	8
HP3	TS-2248202	Socket Head Button Screw.....	M8x20	4
HP4	F009884	Socket Head Button Screw.....	M5x8	4
HP5	TS-1550061	Flat Washer	8mm	20
HP6	TS-2311081	Hex Nut	M8	12
HP7	TS-2361081	Lock Washer	8mm	4
HP8	F009484	Hex Cap Screw.....	M8x65	1
HP9	JWBS14SFXHP9	Large Flat Washer	24x8x2mm	4

JWBS-14SFX Stand (#714402) – Parts List

Index No	Part No	Description	Size	Qty
	714402	Band Saw Stand Assembly (#421 thru 428)		1
421	JWBS14SFX-421	Stand Base		2
422	JWBS14SFX-422	Stand Plate		2
423	JWBS14SFX-423	Rubber Foot		4
HP1	TS-1504101	Socket Head Cap Screw	M8x50	4
HP2	TS-2228161	Hex Cap Screw	M8x16	8
HP5	TS-1550061	Flat Washer	8mm	20
HP6	TS-2311081	Hex Nut	M8	12
HP7	TS-2361081	Lock Washer	8mm	4
	JWBS14SFX-429	JET Stripe, JWBS-14SFX (not shown)		1

Miter Gauge Assembly for JWBS-14SFX Band Saw* (Optional Accessory)

Index No	Part No	Description	Size	Qty
	JWBS14SFX-300	Miter Gauge Assembly (#301 thru 322)		1
301	JWBS14SFX-301	Miter Gauge Handle		1
302	TS-1550061	Flat Washer	8mm	1
303	JWBS14SFX-303	Miter Gauge		1
304	TS-1534041	Flat Head Machine Screw	M5x10	1
305	JWBS14SFX-305	Pointer		1
306	JWBS14SFX-306	Pointer Base		1
307	JWBS14SFX-307	Shaft		1
308	JWP208-053A	Flat Head Machine Screw	M5x8	1
309	JWBS14SFX-309	Washer		1
310	JWBS14SFX-310	Screw		1
311	JWBS14SFX-311	Sliding Guide		1
312	TS-2284202	Pan Head Machine Screw	M4x20	3
313	TS-1540021	Hex Nut	M4	3
314	JWBS14SFX-314	Scale		1
315	TS-1533032	Pan Head Machine Screw	M5x10	2
316	JWBS14SFX-316	Cap A		1
317	JWBS14SFX-317	Miter Gauge Fence		1
318	JWBS14SFX-318	Cap B		1
319	JWBS14SFX-319	Carriage Bolt	M6x30	2
320	TS-1550041	Flat Washer	6mm	2
321	JWBS14SFX-321	Thumbnut	M6	2
322	F011652	Self-Tapping Screw	#8x3/8"	2

Optional Accessory* – Blade & Push Stick

Index No	Part No	Description	Size	Qty
104	JWBS14SFX-104	Push Stick, Red		1

* Optional Accessory – see your dealer to order.

Wiring Diagram for JWBS-14SFX Band Saw

JT1-394..... ~ 230V, 50Hz

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C1	Condenser of running	Kondensator	condensateur
C2	Condenser of Starting	Kondensator	condensateur
n	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
LS	limit switch	Positionendschalter	micro
SB	E-stop	Not-Aus Taster	arrêt d'urgence

